	NuStart
1	RUN
N/C	RUN CAP (No Connection needed)
2	ACTIVE
3	START WINDING
N/C	NOT USED
4	COMMON