NuStart 1 - HI	
1	RUN
N/C	RUN CAP
2	ACTIVE
3	START WINDING
N/C	NOT USED
4	COMMON

NuStart 2 - LO	
5	RUN
N/C	RUN CAP
6	ACTIVE
7	START WINDING
N/C	NOT USED
8	COMMON

* Note: This connection can be made directly into the T1 terminal