




	NuStart
1	RUN
No Connection	RUN CAP (NOT USED)
2	ACTIVE
3	START WINDING
No Connection	NOT USED
4	COMMON