



NuStart	
1	RUN WINDING
N/C	NOT USED
2	SWITCHED
3	ACTIVE/NEUTRAL
N/C	START WINDING
4	