




NuStart

- | | |
|-----|---------------|
| 1 | RUN |
| 2 | RUN CAP |
| 3 | ACTIVE |
| 4 | START WINDING |
| N/C | NOT USED |
| 5 | COMMON |