

| NuStart |               |
|---------|---------------|
| 1       | RUN           |
| N/C     | RUN CAP       |
| 2       | ACTIVE        |
| 3       | START WINDING |
| N/C     | NOT USED      |
| 4       | COMMON        |

