

NOTE:
JUMPER #3 (JP3) MUST BE CUT
WHEN USING LOW PRESSURE SWITCH.

The diagram illustrates the electrical connections for a pressure washer system. It features a **START RELAY** with terminals 1, 2, and 5. A **CONTACTOR** has terminals 1, 2, and 4. Two capacitors, **START CAP** and **RUN CAP**, are shown. Wires are color-coded: **ORANGE #12**, **WHITE #12**, and **BLACK #12**. A **JUMPER #3** is located between the **RUN CAP** and the **CONTACTOR**. Red 'X' marks indicate where to cut the **ORANGE #12** and **WHITE #12** wires. Red numbers 1, 2, and 4 are also present near the **CONTACTOR** terminals.

	NuStart
1	RUN
N/C	N/C
2	ACTIVE
3	START WINDING
N/C	NOT USED
4	COMMON