


POWER SUPPLY PER LOCAL CODES.
SEE NAMEPLATE FOR LINE VOLTAGE.

L'ENTRETIEN PEUT ENTRAÎNER DES
BLESSURES CORPORELLES SEVERES
OU LA MORT.

CAUTION

USE COPPER CONDUCTORS ONLY!
UNIT TERMINALS ARE NOT DESIGNED
TO ACCEPT OTHER TYPES OF CONDUCTORS.
FAILURE TO DO SO MAY CAUSE DAMAGE
TO THE EQUIPMENT.



NuStart

- 1 RUN
- 2 RUN CAP
- 3 ACTIVE
- 4 START WINDING
- N/C NOT USED
- 5 COMMON