049 & 061 Models



CA COOLING ANTICIPATOR
CBS COIL BOTTOM SENSOR
CF FAN CAPACITOR
CN WIRE CONNECTOR
CPR COMPRESSOR
CR RUN CAPACITOR
CS STARTING CAPACITOR
CSR CAPACITOR SWITCHING RELAY
DFC DEFROST CONTROL
F INDOOR FAN RELAY
HA HEATING ANTICIPATOR
HPCO HIGH PRESSURE CUTOUT SW.
IOL INTERNAL OVERLOAD PROTECTOR
ACR A/C RECTIFIER
LPCO LOW PRESSURE CUTOUT SW.
MS COMPRESSOR MOTOR CONTACTOR
ODA OUTDOOR ANTICIPATOR
OFT OUTDOOR FAN THERMOSTAT
ODS OUTDOOR TEMPERATURE SENSOR
ODT OUTDOOR THERMOSTAT
RHS RESISTANCE HEAT SWITCH
SC SWITCHOVER VALVE SOLENOID
SM SYSTEM "ON-OFF" SWITCH
TDL DISCHARGE LINE THERMOSTAT
TNS TRANSFORMER
TS HEATING-COOLING THERMOSTAT
TSH HEATING THERMOSTAT
R OFT SHUNT RESISTOR

COLOR OF WIRE
BK/BL BLACK WIRE WITH BLUE MARKER
COLOR OF MARKER

BK	BLACK	OR	ORANGE	YL	YELLOW
BL	BLUE	RD	RED	GR	GREEN
BR	BROWN	WH	WHITE	PR	PURPLE

	NuStart
1	RUN
2	RUN CAP
3	ACTIVE
4	START WINDING
N/C	NOT USED
5	COMMON

049 & 061 Models



CA COOLING ANTICIPATOR
CBS COIL BOTTOM SENSOR
CF FAN CAPACITOR
CN WIRE CONNECTOR
CPR COMPRESSOR
CR RUN CAPACITOR
CS STARTING CAPACITOR
CSR CAPACITOR SWITCHING RELAY
DFC DEFROST CONTROL
F INDOOR FAN RELAY
HA HEATING ANTICIPATOR
HPCO HIGH PRESSURE CUTOUT SW.
IOL INTERNAL OVERLOAD PROTECTOR
ACR A/C RECTIFIER
LPCO LOW PRESSURE CUTOUT SW.
MS COMPRESSOR MOTOR CONTACTOR
ODA OUTDOOR ANTICIPATOR
OFT OUTDOOR FAN THERMOSTAT
ODS OUTDOOR TEMPERATURE SENSOR
ODT OUTDOOR THERMOSTAT
RHS RESISTANCE HEAT SWITCH
SC SWITCHOVER VALVE SOLENOID
SM SYSTEM "ON-OFF" SWITCH
TDL DISCHARGE LINE THERMOSTAT
TNS TRANSFORMER
TS HEATING-COOLING THERMOSTAT
TSH HEATING THERMOSTAT
R OFT SHUNT RESISTOR

COLOR OF WIRE
BK/BL BLACK WIRE WITH BLUE MARKER
COLOR OF MARKER

BK	BLACK	OR	ORANGE	YL	YELLOW
BL	BLUE	RD	RED	GR	GREEN
BR	BROWN	WH	WHITE	PR	PURPLE