DIRECTIONS FOR USE:

This product must be used in accordance to the following directions by HVACR professionals only.

Apply a uniform coating liberally on the surfaces wherever leaks are suspected. Visually examine surfaces for signs of foam or small bubble formation. Be patient - wait a minimum of 5 minutes. Check bottom of all fittings for increased bubbles/foam. If a leak is found in a refrigeration system, consider Nu-Calgon's EasySeal if the situation is appropriate.

NOT FOR USE ON OXYGEN SYSTEMS.

Authorized by the U.S.D.A. for use in federally inspected meat and poultry plants.

WARNING: This product can expose you to chemicals including formaldehyde, which is known to the State of California to cause cancer, and methanol, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings. ca.gov.





Made in the U.S.A. . Nu-Calgon 2611 Schuetz Rd. • St. Louis, MO 63043 Customer Service: 800-554-5499 Chemical Emergency: 800-424-9300 www.nucalgon.com

(618) Calgon is a licensed trade name.

Nu-Calgon 4180-53

Gas Leak Detector

MICRO GAS LEAK DETECTOR

Non-Freezing

High Viscosity Formulation

Non-Corrosive

FOR PROFESSIONAL USE ONLY





WARNING

Flammable liquid and vapor. Causes serious eye irritation. Suspected of causing cancer.

PREVENTION: Keep away from heat/ sparks/open flames/hot surfaces. No smoking. Keep container tightly closed. Ground/bond container and receiving equipment. Use explosionproof electrical/ventilating/lighting equipment. Use only non-sparking tools. Take precautionary measures against static discharge. Wash thoroughly after handling. Obtain special instructions before use. Do not handle until all safety precautions have been read and understood. Wear protective gloves/ protective clothing/eve protection/face protection.

RESPONSE: If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. In case of fire: Use appropriate media to extinguish. If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. If exposed or concerned: Get medical advice/attention.

STORAGE: Store in a well-ventilated place. Keep cool. Store locked up.

KEEP OUT OF REACH OF CHILDREN.

DISPOSAL: Dispose of contents/ container in accordance with local/ regional/national/international regulations.

Contains: Isopropanol (CAS# 67-63-0)

6 fl. oz. (177mL)